

324444245304354



# **GCC & Cross Compilation**

**Isfahan Linux User Group**


# GCC & Cross Compilation

- GNU Compiler Collection (GCC)
- Compile
- Cross Compile
- Avr-gcc (WinAVR – eclipse)
- GNU ARM

# GNU Compiler Collection (GCC)

- Microsoft Windows, Linux, BSD, Mac
- C, C++, Objective-C, Objective-C++, Fortran, Java, Ada, Go
- Multi-architecture support ٤٠ (AVR, ARM, PowerPC, ...)
- Optimization (O٠ ~ ٣, OS)
- IDE (Eclipse)
- `-std=C٩٩ - gnu٩٩ - C١١ - gnu١١`
- `-nostartfiles`

# Compile



# Cross Compile

- Architecture.
  - 80x86 (uP , CISC)
  - Arm (uC, RISC)
  - Avr (uC, RISC)
  - Power PC (uC, RISC)
- Toolchain
  - Avr-gcc
  - GNU ARM
- Uses of cross compilers
  - Embedded computers (ex. Windows Mobile, Android)
  - Compiling for multiple machines

```
File Edit View Tools Window Help
C/C++ dx Find
index.php | snap.h | snap.c
49
50 // -----
51 // setzt den status zurück
52
53 void snap_reset(tSNAPstatus *status)
54 {
55     status->status = S_SYNCBYTE;
56     status->_pos = 0;
57     status->_p = NULL;
58 }
59
60 // -----
61 // wertet das naechste Byte des Datenstroms aus
62
63 uint8_t decode_snap_stream(tSNAPstatus *snap, uint8_t data)
64 {
65     uint8_t status = snap->status;
66
67     switch (status) {
68     case S_SYNCBYTE:
69         if (data == SYNC) {
70             snap->status = S_HDB2;
71         }
72         break;
73
74     case S_HDB2:
75         snap->msg->hdb2 = data;
76         snap->status = S_HDB1;
```

```
Output
Compiling C: snap.c
avr-gcc -c -mmcu=atmega168 -I. -gdwarf-2 -DF_CPU=8000000UL -Os -funsigned-char -funsigned-bitfields -fpack-struct -fshort-
Linking: snap.elf
avr-gcc -mmcu=atmega168 -I. -gdwarf-2 -DF_CPU=8000000UL -Os -funsigned-char -funsigned-bitfields -fpack-struct -fshort-e
Creating load file for Flash: snap.hex
avr-objcopy -O ihex -R .eeprom snap.elf snap.hex
```

# Avr-Eclipse

File Edit Refactor Navigate Search Run Project AVR Window Help

Upload current project to Atmel target MCU. (Ctrl+Alt+U)

```
* Created on: Dec 21, 2008
* Author: matt
*/

#include <avr/io.h>
#include <util/delay.h>

int main (void){
    DDRB = 0xFF;
    while(1){
        PORTB = 0xFF;
        _delay_ms(500);
        PORTB = 0x00;
        _delay_ms(500);
    }
}
```

Project Explorer

- AI stuff
- AvrTest
  - Binaries
  - Includes
    - /usr/avr/include
    - /usr/lib/gcc/avr/4.3.0
    - /usr/lib/gcc/avr/4.3.0
  - Debug
  - Release
    - AvrTest.elf - [avr/le]
    - main.o - [avr/le]
    - AvrTest.hex
    - AvrTest.map
    - main.d
    - makefile
    - objects.mk
    - sources.mk
    - subdir.mk
  - main.c
- Fractals
- Sudoku
- SudokuProject

Outline

- avr/io.h
- util/delay.h
- main(void) : int

Problems Tasks Console Properties AVR Device Explorer

ATmega324P source: avr/iom324.h >> avr/iomxx4.h


Name	Description	Addr	Bits
ACSR		IO 0x30	8
ADC	Combine ADCL and ADCH	MEM 0x78	16
ADCH	Combine ADCL and ADCH	MEM 0x79	8
ADCL	Combine ADCL and ADCH	MEM 0x78	8
ADCSRA		MEM 0x7A	8

Writable Smart Insert 17 : 22

# Avr Studio

25444542204224

Welcome to AVR Studio 4



Ver 4.12.490

Create new project

Project type:

- Atmel AVR Assembler
- AVR GCC

Project name:

sample

Create initial file     Create folder

Initial file:

sample .c

Location:

C:\temp\temp\AVRStudioGCC\T Est1

<< Back    Next >>    Finish    Cancel    Help



# GNU ARM

Properties for lpc2478

## Settings

Configuration: ARM [ Active ]

Manage Configurations...

Tool Settings Build Steps Build Artifact Binary Parsers Error Parsers

### GCC C++ Compiler

Command: /home/noBackup/arm/gnuarm-4.0.2/bin/arm-elf-g++

All options: -O2 -Wall -c -fmessage-length=0 -mcpu=arm7tdmi-s

Expert settings:

Command line pattern: \${COMMAND} \${FLAGS} \${OUTPUT\_FLAG}\${OUTPUT\_PREFIX}\${OUTPUT} \${INPUTS}

### GCC C Compiler

- Preprocessor
- Symbols
- Includes
- Optimization
- Debugging
- Warnings
- Miscellaneous

### GCC C++ Linker

- General
- Libraries
- Miscellaneous
- Shared Library Settings

### GCC Assembler

- General

Restore Defaults

Apply

OK

Cancel

